

## TIP NUTS

PART NO.	CUTTING TORCHES / CUTTING ATTACHMENTS	TIPS
6259B	133, 142, 198, 42-4, 49-3, 62-5, 72-3, 73-3, 242, 273	6290
2859	28, H28	2890
9008437	36-2	3690
4559	59-3, 880-NM, NM-250, 242-NM, 273-NM	8290
9002537	573, 980	6290
9005236	V-Series	1-101-HV
VH24593	VH24	1-101-HV



9002537

6259B

## ROLLER GUIDES & CIRCLE CUTTING ATTACHMENTS



R-69-880

PART NO.	ANGLE	CONNECTION FOR TIPS	CUTTING ATTACHMENTS / CUTTING TORCHES	NOTES
I-69-4	90°	6290	142, 62-5, 42-3, 42-4, 49-3, 572, 72-3, 73-3, 242, 273	Single wheel guide
I-69-5	90°	3690	36-2	Single wheel guide
I-69-6	45° - 135°	6290	142, 62-5, 42-3, 42-4, 49-3, 572, 72-3, 73-3, 242, 273	
I-69-6-HV	45° - 135°	1-101-HV	V-Series	
I-69-7	45° - 135°	3690	36-2	
R-69-3B	90°	6290	142, 62-5, 42-3, 42-4, 49-3, 572, 72-3, 73-3, 242, 273	
R-69-4C	90°	8290	NM-250, 880-NM, 59-3, 242-NM, 273-NM	
R-69-880	90°	6290	880, 573	
R-69-A	90°	2890	28, H28	

## CONVERTERS

PART NO.	FROM (FEMALE)	TO (MALE)
38-2AL	9/16"-18-UNF-3B-LH	.622"-18-UN-LH
38-2AR	9/16"-18-UNF-3B-RH	.622"-18-UN-RH
38-2FL	9/16"-18-UNF-3B-LH	M16 x 1,5-6g-LH
38-2FR	9/16"-18-UNF-3B-RH	M16 x 1,5-6g-RH
38-2GBL	9/16"-18-UNF-3B-LH	G 3/8" A-LH-UNI ISO 228
38-2GBR	9/16"-18-UNF-3B-RH	G 3/8" A-RH-UNI ISO 228
38-2GR	9/16"-18-UNF-3B-RH	G 1/4" A-RH-UNI ISO 228
38-4GL	9/16"-18-UNF-3B-LH	G 1/4" A-LH-UNI ISO 228
38-3FL	M16 x 1,5-4H-LH	9/16"-18-UNF-2A-LH
38-3FR	M16 x 1,5-4H-RH	9/16"-18-UNF-2A-RH
38-5GL	G 1/4"-LH-UNI ISO 228	9/16"-18-UNF-2A-LH
38-5GR	G 1/4"-RH-UNI ISO 228	9/16"-18-UNF-2A-RH
38-6GL	G 3/8"-LH-UNI ISO 228	9/16"-18-UNF-2A-LH
38-6GR	G 3/8"-RH-UNI ISO 228	9/16"-18-UNF-2A-RH



38-2GBL

38-2GBR

## NEEDLE VALVES

- ▶ Needle valve for precise flow control can replace outlet nipples on regulators
- ▶ Particularly recommended for laboratory installations

PART NO.	GAS	INLET	OUTLET
52-L	Fuel gas	1/4" NPT	9/16"-18-UNF-LH
52-R	Oxygen	1/4" NPT	9/16"-18-UNF-RH
52-DR	Oxygen	1/4" NPT	1/4" NPT



52-L